

# Assembly, Operating & Maintenance Instructions

buroseating


Remove all items from the carton. Verify all pieces before assembly.

## BURO LINDIS 4 LEG - FABRIC / DILLON PU SEATED







STEP 3. ATTENTION: Position the Seat Plastic Cover (3) over the seat frame, aligning 4 connectors. Push hard directly over each of the 4 connectors until you hear a click to indicate the connectors are locked firmly into place.



ATTENTION: Position the Back Plastic Cover (5) over the back brackets aligning 4 connectors. Push hard directly over each of the 4 connectors until you hear a click to indicate the connectors are locked firmly into place.



## **IMPORTANT: Chair Maintenance Instructions**From time to time, check to make sure the screws are securely tightened. Holes on PP shell are for convenient checking.



## PREVENTATIVE MAINTENANCE & WARNING!

- Use this product only for seating one person at a time.
- Do not use this chair as a step stool/ladder.
- Do not sit on any part of the chair except the seat.
- Do not use this chair on uneven floor surfaces.
- Do not interfere with the operating of the gas lift.
- Do not use chair unless all bolts, screws and knobs are tight. At least every six months check all bolts, screws and knobs to ensure they are tight.
- If any parts are missing, broken, damaged or worn do not use the product until repairs are made using factory authorised parts.
- Dispose of packaging properly.
- Plastic bag is not a toy.
- Do not use plastic bag as a head covering as it may cause suffocation.
- Failure to follow these warnings could result in serious injury.

## PART LIST

KEY	QTY	DESCRIPTION
1	2	4 Leg Frame
2	1	Seat Cushion
3	1	Seat Plastic Cover
4	1	Back Cushion
5	1	Back Plastic Cover
6	2	Steel Bar
7	4	Backrest Screw (Short)
8	4	Seat Screw (Long) & Washer
9	1	Allen Wrench

## CARE & MAINTENANCE

#### **GENERAL CARE**

To maintain the appearance of non-upholstered parts wipe the surface with a clean cloth dampened with a mild detergent solution.

Do not remove any parts for separate cleaning.

Do not saturate the fabric or interior with water or other cleaning liquids.

Do not shampoo clean.

Do not clean with hot water extraction machine.

Do not clean with onsite drycleaning machine.

Protect from direct sunlight, heat and weather.

#### FABRIC UPHOLSTERY CARE

Wipe with a clean cloth dampened with a mild upholstery detergent solution.

A soft bristle brush may be used to remove ingrained soil. Spot clean as above.

Treat spills and stains as soon as possible.

Persistent stains may require treatment by a professional cleaner.

May be cleaned with dry powder cleaners.

Allow to dry thoroughly before reuse.

## VINYL/PU UPHOLSTERY CARE

Wipe with a clean cloth dampened with a mild upholstery detergent solution.

Use only vinyl care products suitable for upholstery vinyl and strictly in accordance with the manufacturer's instructions.

Bleach can be used for disinfecting (5:1 water/bleach solution). Spot clean as above.

Treat spills and stains as soon as possible.

Persistent stains may require treatment by a professional cleaner. Allow to dry thoroughly before reuse.

## FOAM & UPHOLSTERY SPECS\*

#### FOAM

Flame Resistance: Ca117 Section A Part I & Section D Part II

#### UPHOLSTERY

Flame Resistance: Ca117 Section E Class I

\*This applies only to standard Buro stock. Any customer specified upholstery may not meet these specifications.